

LIP-9040C Button Layout



Button Guide

1. **Menu:** access the settings for your phone, such as changing the font and display or changing the configuration.
2. **Directory:** accesses the station, system and internal phone books.
3. **Mute:** mute the call so that the caller cannot hear your voice.
4. **Speed:** assign or use assigned speed dial numbers.
5. **DND (Do-Not-Disturb):** blocks incoming calls. You can also activate Do-Not-Disturb while the phone is ringing - this terminates the call and the caller will get a busy tone.
6. **Hold:** place a call on hold – the caller will receive on-hold music or comfort music.
7. **Transfer:** transfer the current active call
8. **Message:** access message box.
9. **Headset:** if a headset is plugged in this button allows you to toggle between the headset and handset.
10. **Volume control:** adjust the Ring, Headset, Handset, and Speaker volume.
11. **Speaker:** toggle the speakerphone On and Off during a call.
12. **Soft keys:** these buttons are interactive and have a changing function based on the phone's status
13. **Flex keys:** a line, feature or quick dial can be assigned to these buttons.

The LIP-9040C has 12 programmable Flex keys

Phone Directory

Using the Phone Book Directory

Access the stored telephone numbers in your system

Press the **Directory** button followed by one of the following options:

- 1 - for your STATION saved numbers
- 2 - for the SYSTEM saved numbers
- 3 - for all INTERNAL extension numbers

Once selected you can then use the navigation keys to scroll through the list. To alpha dial, first press the button showing the letter you wish to dial – e.g. press 2 for the letter B. Then, press 1, 2 or 3 depending on whether it is the first, second, or third letter on the button - e.g. for the letters **SB**, press 2, then 2 again. For letter **C**, press 2 and then 3. Press **OK** to dial the number.

Voicemail

Accessing your Voicemail

Press the **Message** button followed by one of the following options:

- 1 – accesses messages to give an internal user a call back
- 2 – to access your voicemail
- 3 – to access SMS messages

If you do not know your pin, contact your system administrator

Listening to Voicemail (Options)

Once you have accessed your voicemail inbox here are the options available to you:

- Dial 1 – New messages
 - Dial 2 – Set a greeting
 - Dial 3 – Change password
 - Dial 0 – Return to main menu
- Hang up when finished.

Changing System Date and Time (only at the system attendant phone)

Locate System attendant phone :
Press 0 (Zero) on any phone, the ringing phone will be the system attendant phone to use to make the change (if the phone states invalid then you are at the System attendant phone)

- Press TRANS/PGM button
- Dial 0 4 1
- Prompts for date entry (MM/DD/YY)
- Dial date eg: 281018 (28st October 2018)
- Press HOLD/SAVE or OK button
- Prompts time entry (HH:MM)
- Dial time eg: 1315 (01:15pm)
- Press HOLD/SAVE or OK button

Dealing with calls

Answering an Incoming Call	Lift the handset or press the PICKUP soft key. To answer a call on another extension that is programmed to one of the phones 10 flex keys, press the flashing flex key <i>before</i> lifting the handset. You can also set flex keys for call pick-up and group call pick-up.
Making an External Call	Lift the handset and press a free flex key allocated to a line, or 9 dial to pick up an outside line. Once you have an outside line, dial your number.
Making an Internal Call	Lift the handset. Dial the extension number or press the flex key assigned to the contact.
Rejecting a Call	Press the DND button when a call comes in.
Placing a call on hold	Press the Hold button. To reconnect the call, press the Green flashing flex key.

Parking a call

Parking a call	To park an active external call, press Transfer , dial the park code (i.e. #512 for Park 1), and hang up to return to idle. To retrieve a parked call from any handset, lift the handset and dial the park code.
Camp On (Call Waiting)	When dialling an extension that is engaged, the Camp On feature allows the station to be notified that there is a call waiting. Press your assigned flex key to initiate camp on.

Transferring a call

Transferring a Call	During an active call, press either the Transfer button or the TRANS soft key. Dial the extension number, external number or press the programmed flex key. Either speak to the recipient to announce the call, or simply hang up to complete the call transfer.
Returning to Caller from a Transfer	If you are unable to transfer the call, press the Green flashing flex key or the transfer key again to return to the caller.

Redialling a number

Call Redial	You can assign a flex key to be a redial key. This will redial the last called number.
--------------------	--

Features

Do-Not-Disturb Makes your extension unavailable	Press DND key to activate. Press DND key again to deactivate. <i>Please note that this is not available on the attendant handset.</i>
Ad Hoc Conference Calls 3 way calling	To call the first party, follow "Making an External/internal Call" above for instructions. Once connected press the CONF soft key once Call the second party (as above) Once connected, press the CONF soft key twice to connect the calls.
Programming Call Forward (Routes your calls to another extension/group/speed dial) All these features will override your voicemail functions.	Dial 501 (or assigned feature code) then select one of the following options: 1 - Unconditional Forward (forwards all calls instantly) 2 - Busy Call Forward (Only forward calls when you are on the phone) 3 - No Answer Call Forward (Only forwards calls if you don't answer) 4 - Busy / No Answer Call Forward (Mix of 2 & 3) Dial the extension number To disable all call forwarding, dial 502 (or assigned feature code)

The content of this document is subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson-LG Enterprise shall have no liability for any error or damage of any kind resulting from the use of this document

© Ericsson-LG Enterprise Co., Ltd.

5G Communications Ltd.
Support: 01494 817 817, Sales: 01494 523 523
Phoenix House, Desborough Park Road, High Wycombe, Buckinghamshire, HP12 3BQ
info@5gcomms.com | www.5gcomms.com

